


Patch here 7 + 18 jumpers to remove need of -20V supply, connect -20V line to GND

Backside of PDP11/20 front panel PCB showing all connection points



LAMP-INPUTS	OUTPUTS	POWER	OTHER	(NOT-USED)	TO CONNECTOR	PIN #
					L# - To left connector	
					R# - To right connector	
					as seen from back with	
					gold fingers up	
F-V2	ADRS0					L50
F-U2	EXECUTE					L49
F-T2	ADRS1					L48
F-S2	FETCH					L47
F-R2	DEP-H					L46
F-P2	(DEP-L)					
F-N2	(START-L)					
F-M2	START-H					L45
F-L2	INIT-L					L43
F-K2	S/INSTR-H/CYCLE-L					L42
F-J2	(S/INSTR-L)					
F-H2	HALT-H					L41
F-F2	(HALT-L)					
F-E2	(CONT-L)					
F-D2	DEST					L40
F-C2	GND					L39
F-B2	RUN					L38
F-A2	+5V					L37
E-V2	(EXAM-L)					
E-U2	EXAM-H					L33
E-T2	(LOAD-ADRS-L)					
E-S2	LOAD-ADRS-H					L32
E-R2	-20V				-20V Jumpered to GND	
E-P2	-20V					
E-N2	BUS-D00-L					L31
E-M2	BUS-D01-L					L30
E-L2	D00					L29
E-K2	D01					L28
E-J2	A01					L27
E-H2	A00					L26
E-F2	A03					L25
E-E2	A02					L24
E-D2	D03					L23
E-A2						
D-V2	D02					L22
D-U2	BUS-D02-L					L21
D-T2	BUS-D03-L					L20
D-S2	BUS-D04-L					L19
D-R2	BUS-D05-L					L18
D-P2	A05					L17
D-N2	A04					L16
D-M2	D04					L15
D-L2	A07					L14
D-K2	A06					L13
D-J2	D05					L12
D-H2	D07					L11
D-F2	D06					L10
D-E2	BUS-D06-L					L09
D-D2	BUS-D07-L					L08
D-A2						
C-V2	A09					L07
C-U2	A08					L06
C-T2	D08					L05
C-S2	A10					L04
C-R2	A11					L03
C-P2	D09					R02
C-N2	D11					R04
C-M2	D10					R06
C-L2	BUS-D10-L					R08
C-K2	BUS-D11-L					R10
C-J2	BUS-D12-L					R14
C-H2	BUS-D13-L					R16
C-F2	D12					R18
C-E2	A13					R20
C-D2	A12					R22
C-A2						
C-A1	A14					R24
C-B1	A15					R26
C-C1	D13					R28
C-D1	D15					R30
C-E1	D14					R32
C-F1	BUS-D14-L					R34
C-H1	BUS-D15-L					R36
C-J1	GATE-BUS-SR-H					
C-K1	SR16-L					R38
C-L1	SR17-L					R40
C-M1	A16					R42
C-N1	A17					R44
B-C2	GND					R43
B-A2	+5V					R41
A-T1	GND					
A-L2						
A-K2	+8V					R50
A-J2	+8V					R49
A-F2	-20V				-20V Jumpered to GND	
A-E2	-20V					
A-C2	GND					R46 R45
A-B1	(SR16-H)					
A-A2	+5V					R39
A-A1	(SR17-H)					

PDP 11 CONSOLE PANEL  
 200850  
 3408200-4